

Toner Replacement Instructions

Replacing a Toner Cartridge

When the toner cartridge is empty, the message “Install New [colour name] toner cartridge” appears. Replace the toner cartridge following the procedure below when you see this message.

- 1 Open the front cover.
- 2 Pull out the colour toner cartridge to be replaced.
 - 1) Place fingers in the upper groove and slowly pull out the toner cartridge.
 - 2) When the cartridge has been pulled out more than halfway, support it with your hand while pulling it straight out.
- 3 Shake the new toner cartridge strongly with its label side down to loosen the toner inside.
- 4 Peel off the seal from the side, and then pull out the seal in the direction of the arrow.
- 5 Insert the new toner cartridge until it stops.
(Y) Yellow, (M) Magenta, (C) Cyan, (K) Black
- 6 Close the front cover pressing both edges.

Check out our Youtube page by searching “OE Canada”

